


Scimagic Auto Scan RF Multi Frequency Universal Remote Control Duplicator



Feature

Auto scan type

Multi frequency 280-868mhz
Duplicate rolling code and fixed code
Up to 4 different remotes in 1

Programming

A) Standard

1. Press and hold button 1 and press button 2 four times at same time
2. Release 2 buttons till LED flashed once every three seconds
3. Put original remote in the front of new remote (about 2-3cm), press the original remote button which need to be copied until the LED of new remote flash quickly (LED have regular flashes)
4. Press the button of New remote that you want to use to save the code
5. If you do not copy successfully, please repeat above steps
6. To duplicate a second button, repeat the above steps

B) Automatic matching code

After copy successfully, don't use any remote first, then put the new remote close to the receiver to active it, press and hold the button until the Led of it flash quickly, then you can try it

Emitting seed code

Pressing the button 1 and button 2 at the same time until LED flashes quickly. Release 2 buttons, press the button that you want to emit seed code, it has emitted seed code successfully

AMC: Automatic Matching Code

BFT

- 1) Press and hold button 1 and press button 2 four times at same time, Release 2 buttons till LED flashed once every three seconds
- 2) Put original remote in the front of new remote (about 2-3cm), press and hold the original remote button which need to be copied until the LED will turn on with a fixed light and then emits a double flash very 2 seconds
- 3) Pressing the hidden button or the button 1 and 2 simultaneously in the new models (transmit the seed code of original BFT remote)
- 4) Now the led will flash quickly, press the new remote button that you want to save the code, the LED will off
- 5) Now active the remote with AMC procedure

FAAC and GENIUS

Note: your original remote control must be in a master version

How to recognise a master/slave transmitter:

master: if you press any key of a master transmitter, the LED flashes before becoming steady.

slave: if you press any key of a slave transmitter, the LED goes on immediately with steady light

- 1) Press and hold button 1 and press button 2 four times at same time, Release 2 buttons till LED flashed once every three seconds
- 2) Put original remote in the front of new remote (about 2-3cm), press and hold the original remote button which need to be copied until the LED will turn on with a fixed light and then emits a double flash very 2 seconds
- 3) Pressing and hold the button 2 and 3 simultaneously of original FAAC/GENIUS to transmit the seed code
- 4) While the led of FAAC and GENIUS is flashing, put it close to new remote about 2-3cm, and press the button that you want to copy until the LED will change the frequency of flash (faster than before to confirm the correct copy the code)

V2

- 1) Press and hold button 1 and press button 2 four times at same time, Release 2 buttons till LED flashed once every three seconds
- 2) Put original remote in the front of new remote (about 2-3cm), press and hold the original remote button which need to be copied until the LED will turn on with a fixed light and then emits a double flash very 2 seconds
- 3) Press and hold once again the same button of original remote, the LED of new remote will flash quickly, press the button that you want to save the code, until the LED off
- 4) Now active the remote with AMC procedure

Compatible List

Brand	Model	Brand	Model
ACM (AMC)	TX2, TX2 COLOR, TX4	KEY	900TXB-42R, SUB44, TXB-44R, TXG-44R
ADYX	TE4433H BLUE, 433-HG BRAVO	KINGGATES	STYLO, CLIPPER
AERF	COMPACT, HY-DOM, MERCURI B, MERCURI C, SABUTON, MARS, SATURN, ST3/N, TERRA, TMP-1, TMP-2, UNITECH	KLING	KUA, KUA E, KUA S
		LABEL	SPYCO, RW4E
ALLMATIC (AMC)	BROWN, BROWN RED, BRO.OVER, PASS, MINIFASS	LEB	TMW
APERIO	GO, GO PRO, GO MINI	LINCE	LR2035
APERTO (SOMMER)	TX02-434-2, TX02-868-2 BLUE, 4025 TX02-868-2, 4022 TX02-434-2, 4020 TX03-434, TX-03-868-4, 4013, TX03-434-4	LIFE	LIFE FIDO2 / FIDO4 / VIP2 / VIP4 / VIP2R / VIP4R / STAR2 / STAR4 / BRAVO2 / BRAVO4
APRIMATIC (AMC)	TR2/TR4, TM4, TXM	LINEAR	MCT-11, ACT-22, ACT-21, STING RAY ACT-31, STING RAY ACT-34B
ATA	PTX4 BLUE, PTX4 PINK	MHOUSE (AMC)	GTX4, GTX4C, TX4
AVIDSEN	104251, 104250, 104250 OLD, 104250 RED, 104257, 104350, 654250	MA	TX1, TX2, TX3
		MOOVO (AMC)	MT4G

BALLAN	FM400, FM400E, FM404B, 4013	MARANTEC	D101,D12,DIGITAL302,DIGITAL304		
BENINCA (AMC)	TO.GO.WV, TWV, ROLLKEY, APPLE, LOT WCV, CUPIDO,TO.GO.QV, IO, LOT2WCV,LOT1W, LOT2W, LOT4W, LOT1WM, LOT2WM,T2W, T4W	MERLIN/PROLIFT	M230T(PROLIFT),M430R(PROLIFT)		
		MERLIN 2.0	E945M,E943M,E940M		
BESIDE	BEZAP, HIT	MONSEIGNEUR	ARC		
BFT (AMC)	MITTO, MITTO M(MITTO 2M/MITTO4M), MITTO RCB(MITTO RCB02/MITTO RCB04), MITTOA(MITTO 2A/MITTO 4A), MITTO B,TRC(TRC2/TRC4), GHIBLI, MURALE, KLEIO, TEO1, TEO2,TEO4, RB4 MURALE	NORTON	NEO, TXCD, GO NORTON, GO MINI NORTON		
		NOVOTECNICA (AMC)	BLXL2		
CAME	T431, T434, TOP432A, TOP434a, TOP432, TAM432SA, TOP432NA	NOVOFERM	NOVOTRON 502-504-512MIX43-2,MTX40-2,MCHS43-2,MHS43(2-4),MNHS433(2-4),MCHS, MINI-NOVOTRON504,MICRO-NOVOTRON		
CARDIN (AMC)	TRQ S449 (TRQ449100/TRQ449200/TRQ449300/TRQ449400), TRQ S449 GREEN(PRECODE), TXQ S449(TXQ449200/TXQ449300/TXQ449400), TXQ S449 GREEN, TRQ S486(TRQ486200/TRQ486400), TXQ S486(TXQ486200/TXQ 486200/TXQ486400), S437 TX, XRADO, S449, S476TX2, S476TX, S486	NOLOGO	ECO DIP		
		O&O (AMC)	T.BOM,TWIN,TX,TWIN,TX2/TX4		
		O&G	OG62,OG64		
CASALI	JA33 AMIGO, GENIUS/CASALI A252RC	OPENOUT	TMQ		
CASIT	ERTS92B, ERTS92T, ERTS476D, ERTS20DQ, ERTS476D, ERTS476Q	PECCININ	TX MENBRANA		
CELISA	S10 1, S10 2	PORTAMATIC	MPH01,MPH02		
CENTURION	CLASSIC, SMART	PRATEL	TC2E(4E),SLIM,BFOT,MPSTP2E,MPSTF2,MPSTF4,MPSTF2RE,MPSTF4RE,MPSTP2E,MPSTP2EBL UE		
CHAMBERLIN/ LIFTMASTER/ MOTORLIFT	953ESTD, 371LM(315MHZ), 81LM,971LM(390MHZ),84330E,94334CE, 94333E/94334E/94335E, 9747E, 1A5477, 1A6487, 132B2372, 94330EML/94333EML/94335EML, 84330EML/84333EML/84335EML, 8747EML			PROEM	ER4C4ACS
				PROGET	ETY_433N2,ETY_433N4
CLEMSA	MUTANCODE, T, T-8, E-CODE N, MASTERCOD MV	PROTECO	TX433,EUROMATIC		
CPS	TCP3, CPS1, CPS2, CPS4	PUJOL	MARTE,P215,TWIN,VARIO,VARIO MARS, VARIOOCEAN,NEO		
DASPI (AMC)	HAPPY2, POPS 2, ZERO RC(ZERO 2RC, 4RC)	QUASAR	433		
DEA	TR MIO, 133 1, 433 2, GENIE, PUNTO S2, PUNTO 278, GOLDR, GENIE R 273, GENIE R-GT2N	RIB	LITHILO		
DELMA	MIXARD 433 1, MIXARD 433 2, KING 433 2	ROPER	NEO,GO ROPER,GO MINI ROPER		
DICKERT	MAHS433 01, MAHS433 04	SABUTOM	BROOVER,BROSTAR		
DITEC (AMC)	GOL, GOL4C, BIXLS2, BIXLP2, BIXAG4, BIXLG	SEA	SMART DIP		
DOORMATIC	SAW	SECULUX	NEO		
DOITRAND	MPSTF2E, JAUNE	SEAV	BE HAPPY RS(BE-HAPPY-RS1,BE-HAPPY-RS2,BE-HAPPY-RS3),BE-SMART RSX,BE-HAPPY RH1,BE-HAPPY RH2,BE-HAPPY RH3		
DOORHAN	TRANSMITTER 4				
DUCATI	TSAW1, TSAW2, TSAW3, 124, TE2	SILVELOX	MHZ 2007, QUARZ SAW		
ECOSTAR	RSE,RSC,RSZ	SICE	4790207		
ELBE	501, 502, 504, 502A, 504A	SIMINOR	CVXNL,MITTO,SIM433		
ERREKA	IRIS, ROLLER 2, ROLLER 433, ROLLER 868, SOL433, SOL868, VEGA 433, VEGA 868	SEUCURVERA	SV R2C,SV R4C,SV R6C		
ELCA	IRIS, ASTER,ASTER 1000,ASTER 1001	SERAI	OG/52,OG54,OG82,OG84,OG/28,OG48,OG62,OG64		
FAAC (AMC)	XT 433 RC, TM1 433 DS, TM2 433 DS, TM3 433 DS, 433L2, 433L4, TM2 433 SLP, TM4 433 SLP, TLM 433SLH, TLM 868SLH, DL 868SLH, XT 868SHL, XT 433SHL, T 868SHL, T 433SHL, XT433RC, TE433HG	SOMFY	LEIS,K-EASY,K-EASY NEW,K-EASY OLD,MITTO,KEY GO RTS,TELIS,KEYTIS RTS		
FADINI (AMC)	FADINI JUBI, JUBI SMALL, ASTRO 43 SMALL, 433 M2 ASTRO 433-2, ASTRO 433-4, JUBI2/JUBI4	SOMMER	SOMMER 4026 TX03-868-2,SOMMER 4020 TX03-868-4,SOMMER 4031,SOMMER 4025,SOMMER 4011,SOMMER 4035,APERTO 4025		
FERPORT	TAC1,TAC2, TAC4, TAC 1K, TAC 2K, TAC 4K, TAC2KR	STAGNOLI	KALLISTO,VENUS AV223		
GIBIDI	GIBIDI OPEN TMB, OPEN OUT, AUO1590, AU1600, DOMI- NO AU1680 WOOD, GIBIDI AU1610,GIBIDI AU1680, AU1810, AUO3000,AUO3000 DOMINO,DTC 4334,DTS4334-AUO400	TAU (AMC)	250K-SLIMRP,250K-SLIMR,250T-4RP		
		TELCOMA	FM402,FM402E,FM400E,FM400		
GULLIVER	MDW	TORLIFT	TORMIT4		
GENIUS (AMC)	AMIGO,AMIGOLD,KILO,BRAVO,ECHO	VDS (AMC)	TRQ P,ECO-R		
GENIE (AMC)	GITR-3, GIT, GICT390, GIFT390-1, G3T-BX, G1T-BX, GM3T, GICTD, GIFTD	VARWFORD	EA433 4K,SMART2,SMART3		
HORMANN	HSM2,HSM4	V2 (AMC)	V2 PHOX 2, V2 PHOX 4,V2 PHOENIX 2,V2 PHOENIX 4,V2 TXC,V2 TRC,V2 TSC4,V2 HAND		
JAY	UBEI X 1SL1,UBET 21,UBET 41,UBET 61				
KBLUE	ETH-TEL01				