

GIGAcorn

200-command industrial handheld transmitter



Advantages:

- Compatible with SOMloq2 and Somloq Rollingcode 868.8 MHz radio system
- Controlling of 100 doors (selective opening and closing → this offers 200 commands)
- Preselection of required command via keyboard
- The favourites function enables a direct controlling of one specific door
- Large buttons make operation easy (even with gloves)
- Weather-resistant and perfectly suited for indoor and outdoor use
- The supplied aluminium wall bracket enables the using as a wall-mounted transmitter



Advantages of SOMloq2:

- Maximum protection from hackers with 128 bit AES encryption with Rollingcode.
- Radio receiver confirms received commands, an LED on the transmitter acknowledges receipt
- Commands are forwarded by SOMloq2-compatible receivers

TECHNICAL DATA

Radio system	SOMloq2
Radio commands	200
Frequency	FM 868,8 MHz FM 868,95 MHz
Range ¹⁾	approx. 50 m
Dimensions	147 × 48 × 30 mm
Temperature range	-20 °C to +55 °C
IP code	IP64
Battery	3 V (CR 123A)

1) Depending on surroundings



Disturbance-resistant radio signal



128-bit encryption



Collision resistance



Bi-directional radio control system

Last updated: 03/2016. Literal errors, errors and technical changes excepted.



SOMMER ANTRIEBS- UND FUNKTECHNIK GMBH | HANS-BÖCKLER-STR. 21-27 | D-73230 KIRCHHEIM/TECK
PHONE +49 7021 8001-0 | FAX +49 7021 8001-100 | INFO@SOMMER.EU | WWW.SOMMER.EU

